

After all the welding is done remove this section for the idle adjuster screw clearance at full throttle best method is to drill a 12mm hole then carefully cut the top out

